



Easy Mover Instructions

To Tighten or Loosen Joints



Use a 3/16 inch Hex Wrench with a ball end (included)

