
## Quick Connect Receiver (QCR) to the Quick Release Plate (QRP)



Quick Connect Receiver (QCR) and the Quick Release Plate (QRP). Attach the QCR to the QRP with four screws (8-32 x 1/2 inch) included with the Quick Connect Receiver. \*Note the grooves on the QCR